

Instructions for correct packing of microsensors

1. Placing the first membrane inlay

Place one membrane inlay in the box with the membrane side up.



2. Place sensor on membrane

Place the sensor(s) with protection tube(s) on the membrane but leave the wires hanging outside the box.

To the extent possible, please place the sensor(s) on the membrane.



3. Sensor between the two membranes

Place the second membrane inlay with membrane side down onto the sensor(s).

Secure the wires in the plastic clips on the cardboard part of the upper side of the inlay.



4. Close and ship

Close the lid and push the lid tabs into the slots in the box sides.

